HAKOFX-951

High-output, temperature controlled soldering station

Instruction Manual

Thank you for purchasing HAKKO FX-951 soldering station. Please read this manual before operating the HAKKO FX-951. Keep this manual readily accessible for reference.

1. PACKING LIST AND PART NAMES Please check to make sure that all items listed below are included in the package.

HAKKO FX-951 soldering station	Heat resistant padlron holder
Power cord1	Instruction manual





Tip (not included)



HAKKO FM-2028



Iron holder

2. SPECIFICATIONS

	HAKKO FX-951 soldering station		
Power consumption 75 W		75 W	
	Temperature range	200-450°C (400-840°F)	
ſ	Temperature stability	±5°C (±9°F)	

Power cord

Station

Output	24 V
Dimensions	80 (W) × 130 (H) × 131 (D) mm
Weight	1.2 kg

● HAKKO FM-2028 soldering iron

TIARRO FINI-2020 Soldering Iron			
Power consumption	70 W (24 V)		
Tip to ground resistance	< 2 Ω		
Tip to ground potential	< 2 mV		
Length of cord	1.2 m (4 ft.)		
Length, (w/o cord)	188 mm (7.4 in.) with 2.4D tip		
Weight, (w/o cord)	30 g (0.07 lb.) with 2.4D tip		

NOTE:

- The temperature was measured using the HAKKO 191 or FG-100 thermomete
- * This product is protected against electrostatic discharge
- * This product meets China RoHS requirements
- * Specifications and design are subject to change without

■ Electrostatic Protection

This product includes such features as electrically conductive plastic parts and grounding of the handpiece and station as measures to protect the device to be soldered from the effects of static electricity. Be sure to observe the following instructions

- 1. The handle and other plastic parts are not insulators, they are conductors. When replacing parts or repairing, take sufficient care not to expose live electrical parts or damage insulation materials.
- 2. Be sure to ground the unit during use.

■ 中國RoHS: 產品中有毒有害物質或元素的名稱及含量

	有毒有害物質或元素					
部件名稱	鉛(Pb)	汞(Hg)	鎘(Cd)	六價鉻 (Cr(VI))	多溴聯苯 (PBB)	多溴二苯醚 (PBDE)
焊鐵部	×	0	0	0	0	0
插座	×	0	0	0	0	0
插頭	×	0	0	0	0	0

- 〇: 表示該有毒有害物質在該部件所有均質材料中的含量均在SJ/T 11363-2006 標準規定的限量要求以下
- 表示該有毒有害物質至少在該部件的某一均質材料中的含量超出SJ/T 11363-2006 標準規定的限量要求。

注有「附帶BS插頭」之時,表示「插頭」為含有有害物質的部件。

3. WARNINGS, CAUTIONS AND NOTES

⚠ WARNING

Warnings, cautions and notes are placed at critical points in this manual to direct the operator's attention to significant items. They are defined as follows:

MARNING: Failure to comply with a WARNING may result in serious injury or death.

⚠ CAUTION : Failure to comply with a CAUTION may result in injury to the operator, or damage to the items involved. Two examples are given below.

: A NOTE indicates a procedure or point that is important to the process being described.

EXAMPLE: An EXAMPLE is given to demonstrate a particular procedure point or process.

♠ CAUTION

When power is ON, tip temperatures will be between 200°C and 450°C. (392°F to 840°F.) To avoid injury or damage to personal and items in the work area, observe the following

- Do not touch the tip or the metal parts near the tip.
- Do not allow the tip to come close to, or touch, flammable materials
- Inform others in the area that the unit is hot and should not be touched.
- Turn the power off when not in use, or left unattended.
- Turn the power off when changing parts or storing the HAKKO FX-951

To prevent accidents or damage to the HAKKO FX-951, be sure to observe the following:

- Do not use the HAKKO FX-951 for applications other than soldering.
- Do not allow the HAKKO FX-951 to become wet, or use it when hands are wet.
- Do not modify the HAKKO FX-951.
- Use only genuine HAKKO replacement parts.
- Do not bend or damage the control card. If the card does become damaged, do not force the card into the station slot.
- Do not strike the iron against hard objects to remove excess solder. This will damage the iron.
- Be sure the work area is well ventilated. Soldering produces smoke
- While using HAKKO FX-951, don't do anything which may cause bodily harm or physical damage.

4. INITIAL SETUP

 Loosen the adjusting screws to change the angle of the iron receptacle as you like, then tighten the

• Put the tip cleaner (599B) in the cleaner base.




⚠ CAUTION

Do not set up the iron eceptacle too high, the temperature of the soldering iron will become very hot.

⚠ CAUTION

Do not lay down the iron receptacle too much, it can be easy to fall down



Use of the sleep function

When using the sleep function, insert one end of the connecting cable into the jack at the back of the iron holder and the other end into the jack at the back of the soldering station to connect them.

⚠ CAUTION

Be sure to turn off the power before connecting or disconnecting the connecting cable

B. Handpiece cord assembly

Pass the iron cord through the hole in the heat resistant pad

C. Soldering station


↑ CAUTION


Be sure the power switch is OFF before connecting or disconnecting the soldering iron cord. Failure to do so may result in damage to the circuit board.

- 1. Insert the power cord into the receptacle at the back of the station. Insert the soldering iron cord into the receptacle
- at the front of the station 2. Set the iron in the iron holder
- 3. Plug the power cord into a grounded wall socket.

⚠ CAUTION

The HAKKO FX-951 is protected against electrostatic discharge and must be grounded for full efficiency.





5. OPERATION

Controls and displays

Controls



The front panel of the HAKKO FX-951 soldering station has the following controls:

- · Four control buttons:
- # Initiates a data entry mode.
- * End of sequence signal (terminates a phase of a data entry mode); when pressed for less than one second, displays settings already
- Increases the value in the appropriate display window.
- Decreases the value in the appropriate display window.

Displays

The HAKKO FX-951 has a three-digit display element. Depending upon the selected mode, it will display:

- Normal mode:
- Sensor temperature (tip temperature)
- Data entry: Selected quantity (See 'data entry procedures' for exact characteristics.)
- Temperature scale
- °C or °F, depending upon selection
- Error detection
- Refer to 'ERROR MESSAGES' section.

In addition, heater lamps will flash when the station has reached the desired temperature, indicating that it is ready for use

- An audible buzzer is provided to alert the operator when:
- · The station has reached the set temperature. The buzzer will sound once.
- When the low temperature threshold has been crossed, the buzzer will sound continuously. This buzzer will shutoff when the sensed temperature returns to the acceptable range.
- When a foreign substance, an incompatible tip, or the soldering end of the tip is inserted into the HAKKO FM-2028, the display will blink and the buzzer will sound continuously.
- When the error occurs with the HAKKO FM-2028, the buzzer will sound continuously.

Operation

- 1. Turn the power switch ON.
- 2. Once the temperature is reached, the buzzer sounds. The heater lamp at the lower right of the temperature display 350 starts blinking.

⚠ CAUTION

The HAKKO FX-951 is preset at 350°C at the factory. Check the temperature setting by pressing the *\text{button}. The set temperature will be displayed for two seconds.

Place the iron in the iron holder when not in use.

Setting/changing the temperature

Example: 350°C to 400°C

1. Insert the control card into the slot in the front of the unit

· The hundreds digit will begin to flash, indicating that the unit is in the TEMPERATURE SET mode and data may be entered.

2. Entering the hundreds digit

 Press the or button to set the desired figure. Only 2, 3, or 4 can be selected. (In °F mode, 4, 5, 6, 7, or 8 can be selected). When the desired figure is displayed, press the (*) button to enter. The tens digit will begin to flash.

3. Entering the tens digit

 Press the or button to set the desired figure. Any value from 0 to 9 can be selected. (In °F mode, the same value can be selected.) When the desired figure is displayed, press the * button to enter. The units digit will begin to flash.

4. Entering the units digit

Press the or button to set the desired figure. Any value from 0 to 9 can be selected. (In °F mode, the same value can be selected.) When the desired figure is displayed, press the * button to enter. The desired temperature is now entered into the system memory and heater control will begin.

Press the ▲ or ▼ button. Press the * button once. Press the (▲) or ▼) button. Press the \star button once. Press the * button once 400

NOTE:

If power is switched off or lost during the execution of this procedure, no data will be entered. The entire procedure must be repeated from step 1.

When the station is ON and the card is in the station, the data entry procedure follows:

- 1. Hold the * button down for at least one second. The current temperature setting will be displayed, then the hundreds digit will begin to flash. This indicates that the station has entered the temperature setting mode Continue with the procedure of 2 - 4, above.
- 2. When the *button is pressed for less than one second, the current temperature setting is displayed for two seconds, then returns to show the actual tip temperatures.

Replacing the tip

∆ CAUTION

he tip may be hot. Avoid holding the hot tip for a long time even if using the heat-resistant pad. Otherwise burns may result.

Removing the tip:

Hold down the lock release buttons in the sleeve assembly, pull out the tip together with the sleeve assembly from the connector.

⚠ CAUTION

- Be sure to keep the lock release buttons hold down while pulling out the sleeve assembly. Failure to do so will damage the locking mechanism.
- Be sure to pull out the tip only after separating the sleeve assembly from the connector. Otherwise, the sleeve assembly may fall down and break.
- · Holding the front end of the sleeve assembly, pull out the tip

Inserting the tip:

Holding the front end of the tip, insert it into the


∆ CAUTION

sert the tip into the sleeve assembly until it clicks into place. When you hear it clicks, avoid forcing the tip into the sleeve assembly.

Insert the tip securely into the connector.

NOTE:

Improper insertion of the tip will cause 5-E to appear on the display





Hold this part to insert the tip into the sleeve assembly.

⚠ CAUTION

When holding the head of the tip, there is a danger of burn. Be sure to use the heat-resistant pad



Hold this part to insert the tip into the connector

• How to enter the tip offset value into the **HAKKO FX-951**

Example 1:

If the measured temperature is 410°C and the set temperature is 400°C, the difference is -10°C (need to decrease by 10°C). So, enter the figure which 10 is deducted from present offset value

1. Insert the control card into the slot in the station

- The station is in the temperature setting mode The hundreds digit will begin to flash.
- 2. Press the # button on the front panel. · This will set the station to offset value entry

3. Enter the offset value

The allowable ranges for offset values are from -50 to +50°C (In °F mode from -90 to +90°F).

NOTE:

mode

During offset data entry mode with blinking the tip temperature is controlled by present

a. Entering the hundreds digit

 Press the ▲ or ▼ button to set the desired figure. Only 0 (plus) or - (minus) can be selected. (In °F mode, it is the same as °C mode). When the 0 (plus) or - (minus) is selected, press the * button to enter. The tens digit will begin to flash.

b. Entering the tens digit

· Press the ▲ or ▼ button to set the desired figure. Any value from 0 to 5 (In °F mode, 0 to 9) can be selected. When the desired figure is displayed, press the * button to enter. The units digit will begin to flash.

c. Entering the units digit

 Press the ▲ or ▼ button to set the desired figure. Any value from 0 to 9 (In °F mode, same value can be selected.) When the desired figure is displayed, press the * button to enter. The desired temperature is now entered into the system memory and heater control will begin with new offset value.

Insert the card. \/ Press the # button Press the ▲ or ▼ Press the * button once. Press the ▲ or ▼ Press the * button once. Press the * button once.

When the unit is in offset-free mode, you can go into the offset value entry mode without control card by pressing the # button for second.

When the station is ON and the card is in the station, the offset entry procedure follows:

- 1. Hold the # button down for at least one second. The current offset value will be displayed, then the hundreds digit will begin to flash. This indicates that the station has entered the offset value input mode. Continue with the procedure of a - c. above
- 2. When the button is pressed for less than one second, the current offset value is displayed for two seconds, then returns to tip temperature

6. PARAMETER SETTINGS

The HAKKO FX-951 comes from the factory with the following values preset.

emperature scale	Celsius
Power save	0 min.
ow temperature alarm setting	150°C
Resetting the supervisor or	4 0
perator control setting	
Setting temperature	350°C

Entering the parameter

1 °C or °F temperature display

2 Power save setting

Set the time from the placement of the soldering iron on the iron holder to the activation of the sleep function.

When not using the power save function, do not connect the iron holder and the soldering station with the connecting cable

Power save example:

- 2 0 Sleep (immediately after the soldering iron is placed on the iron holder)
- 210 Sleep (10 minutes after the soldering iron is placed on the iron holder) 230 Auto-power shutoff (30 minutes after the

soldering iron is placed on the iron holder)

The power save time can be set in steps of one minute (30 minutes max.)

- The sleep function is activated and the temperature of the tip begins to drop. The buzzer sounds once.
- When the display shows \(\frac{5LP}{P} \), pressing any button the power will be turned on again.

The sleep function does not work in case the setting temperature is less than 300°C/570°F.

- When the auto-power shutoff function is activated and power to the heater is shut off, the buzzer sounds three
- When the display shows - , and to begin soldering, cycle the power switch OFF, then ON.

3 Resetting the low temperature alarm tolerance setting

The unique function alerts the operator when the sensed temperature drops below a set limit. Should this occur, an error message will be displayed, and the buzzer will sound continuously. When the temperature returns within the allowable range, the buzzer will stop.

Range of allowable low temperature alarm tolerance for °C: 30 - 150°C for °F: 50 - 300°F

Example:

When the setting temperature is 350°C and the low temperature alarm tolerance is 100°C, buzzer will sound when the tip temperature will drop over 250°C.

4 Resetting the supervisor/operator control settina

The HAKKO FX-951 has the following four parameters:

- 1) °C or °F temperature display selection 2) Power save
- 3) Low temperature alarm setting
- 4) Resetting the supervisor/operator control

Once the station enters parameter mode, set the parameters in the order shown below. After all the parameters have been set, normal operation will be resumed

- 1. Turn power OFF.
- 2. Insert the control card into the card slot in the front of the unit.
- 3. Press and hold down the ▲ and ▼ buttons simultaneously, and then turn power ON.
- 4. Hold ▲ and ▼ buttons down until the display shows [[Celsius) or [F (Fahrenheit).

When either the display shows either / Cor *I F* the station is in parameter input mode.

- Pressing either the ▲ and ▼ button will cause the display to alternate between [! [or [! F]. When the desired scale is displayed, select by
- pressing the * button. The system will automatically sequence to power save mode.


When the station enters the parameter input mode, the procedure is as follows.






▼ (20 times)














er will be automatically shut off (auto



- When the station enters low-temperature alarm tolerance setting mode, the hundreds digit begins flashing. Enter and store the value in the same manner as described in "Changing the temperature setting
- If you enter a value exceeding the allowable range shown to the left, you will be brought back to entering a value in the hundreds digit. If this occurs, reenter a correct value.
- Once the value is stored, the system will automatically sequence to resetting the supervisor/operator control setting mode.

To change the supervisor/operator control settings, the procedure is as follows

- The display will show 4 1 or 4 1 when this mode is entered
- Y 🗓 : No offset value can be entered without inserting the card. Y: An offset value can be entered without

Pressing the or button will change 4 1 and 🛂 🝴. When the desired setting is displayed, select by

inserting the card.

pressing * button. The system will exit the parameter setting mode and begin heater control

It is now ready for normal operation.

7. ERROR MESSAGES

Sensor Error



Low-temperature alarm tolerance error



FXAMPIF

350°C (400°C - 50°C) Set temperature - Low-temperature alarm tolerance OR 650°F (<u>750°F</u> – <u>100°F</u>) Set temperature Low-temperature alarm tolerance

Heater terminal short circuit error



Soldering iron error



When there is the possibility that a failure has occurred in the sensor or heater (including the sensor circuit), $5-\mathcal{E}$ is displayed and the power is shut down.

⚠ CAUTION

The sensor error also occurs if the tip is not inserted properly.

If the sensor temperature falls below the difference between the current temperature setting and the low-temperature alarm tolerance, [H-E] is displayed and the warning buzzer sounds. When the tip temperature rises to a value within the set tolerance, the buzzer will stop sounding.

EXAMPLE:

Assume that the temperature setting is 400°C/750°F and the tolerance 50°C/100°F. If the temperature continues to decrease and finally falls below the value indicated below while the heating element is on, the displayed value starts blinking to indicate that the tip temperature has

HSE will flash, and the buzzer will sound continuously, when the tip is inserted wrong way round, an incompatible tip is inserted, or a foreign object has found its way into the connector.

 $\boxed{\mathcal{L} - \mathcal{E}}$ will be displayed if the connector cord is not attached to the station OR the wrong soldering iron is connected

҈HAK《O

HAKKO CORPORATION HEAD OFFICE

TEL:+81-6-6561-3225 FAX:+81-6-6561-8466 OVERSEAS AFFILIATES

U.S.A.: AMERICAN HAKKO PRODUCTS TEL: (661) 294-0090 FAX: (661) 294-0090 Toll Free (800)88-HAKKO 42 556 http://www.hakkousa.com http://www.hakkousa.com HONG KONG: HAKKO DEVELOPMENT CO., LTD TEL: 2811-5588 FAX: 2590-0217

E-mail:info@hakko.com.hk SINGAPORE: HAKKO PRODUCTS PTE., LTD. TEL: 6748-2277 FAX: 6744-0033

Please access to the following address for the other Sales affiliates

http://www.hakko.com Copyright @ 2004 HAKKO Corporation. All Rights Reserved.

MA01472JZ070507