



Keep this manual readily accessible for reference.

Please check to make sure that all items listed below are included in the package.

The diagram illustrates the HAKKO FR-872 reflow soldering unit. The main unit is shown from a top-down perspective, highlighting the lamp cover, cross bars, P.W.B. holder, and the rear panel with power and fuse receptacles. A detailed view of the lamp cover shows its mesh pattern. A separate view shows the heater and thermocouple components. The control panel at the bottom features a power switch, T/C connector, SET indicator, ADJ knob, T/C indicator, zone selector switch, power mode selector, and MODE buttons for start/stop and heating area.

Labels and Components:

- Lamp cover
- Cross bar (x2)
- P.W.B. holder (x4)
- Heater
- Thermocouple
- HAKKO FR-872 rear
- Power receptacle 100 - 120V
- Fuse holder
- Power receptacle 220, 230V
- Fuse holder
- Power cord
- HAKKO FR-872
- Power switch
- T/C connector
- SET indicator
- ADJ knob
- T/C indicator
- Zone selector switch
- Power mode
- T/C mode
- Auto mode
- MODE button
- START / STOP button
- Heating area

Power consumption	100V-1050W 110V-1250W 120V-1440W 220V-1150W 230V-1250W
Dimensions	360(W) × 97(H) × 535(D) mm (AC100 - 120V) / 360(W) × 97(H) × 524(D) mm (AC220, 230V)
Weight (w/o cord)	5.6 kg
Mode	Power mode 0 - 100% T/C mode 50 - 200°C (122~392°F)



* This product is protected against electrostatic discharge.
* Specifications and design are subject to change without notice.

This product contains electrostatic countermeasures, so please use the following precautions:

1. Not all plastic parts are insulators, they may be conductive. Be careful not to expose live electrical parts or damage insulating materials when performing repairs or replacing parts.
2. Be sure to ground the product before use.




Fit the P.W.B. to the FR-872. (Figure 1)



Ensure the front cross bar is secure. Place one edge of the P.W.B. against the holder clips. Bring the rear cross bar into contact with the opposite edge of the P.W.B. so that the holder clips secure the P.W.B..

Please refer to the HAKKO FM-206 / FM-2029 instruction manual for its use.



Timing diagram for the 74VHC163 3-bit counter. The diagram shows the relationship between several inputs and the counter's output over time. The inputs are: POWER (ON/OFF), START / STOP (ON/OFF), CONTROL (ON/OFF), ALARM (ON/OFF), Output in normal mode (ON/OFF), Output when error occurs (ON/OFF), and External input (ON/OFF). The counter's output is shown as a series of pulses. The diagram is divided into three sections: Normal Operation, When error occurs, and External input. In Normal Operation, the counter counts from 0 to 7. In When error occurs, the counter stops at 7. In External input, the counter stops at 7 and then counts from 0 to 7 again.


7. MAINTENANCE

In order for you to use the preheater in optimum condition for a long time, it is important that you perform maintenance work on a regular basis. The degree of wear and tear the preheater may incur varies depending on the temperatures it is used at and the environment it is used in. Provide appropriate care according to the conditions of its use.

⚠ WARNING


When replacing the heater:
•Make sure the heater and lamp cover have sufficiently cooled.
•Be careful for any injures which may be caused by sharp edges on the lamp cover.

■ Burned-out heater



Measure the resistance value between the terminals.

■ Replacing the heater




⚠ CAUTION

Do not subject the heater to excessive impact.
Do not hold the heater by its glass portion at the center with bare hands.
For replacement, hold the end of the heater, and detach it from the socket at an angle.

⚠ CAUTION


Mount the heater so that the sealing at the center faces downward (on the reflector side).
Be sure that the grounding wire of the lamp cover is properly connected.



Mount the heater so that the protrusion faces downward.

Specifications : 40V 120W Terminal : Brown (100-120V)
Specifications : 80V 250W Terminal : White (220-240V)

■ Replacing the Fuse



Rotate it counterclockwise and remove.

1. Disconnect the power cord from the power receptacle.

2. Pull the fuse out of the fuse holder.

3. Replace the fuse with a new one.

4. Put the fuse holder back in place.

8. TROUBLESHOOTING

⚠ WARNING

Be sure to disconnect the power plug before inspecting the inside of the preheater or replacing its part to avoid electric shocks.

● The unit does not operate when the power switch is turned on.

CHECK

Is the power cord or the power plug disconnected?

ACTION

Connect the cord or the plug.

CHECK

Has the fuse blown?

ACTION

Find out why the fuse has blown; then, replace the fuse. If the fuse blows once again, ship the preheater body together with the fuse for necessary repairs.

● The heater is not powered.

⚠ CAUTION

A single block has a set of 3 heaters. Keep in mind that an open circuit in one heater deprives the other heaters in the same block of power.

CHECK

Has the START/STOP button been pressed?

ACTION

Press the START/STOP button.

CHECK

Is the selector switch off?

ACTION

Turn on the selector switch.

CHECK

Is the heater out of the socket?

ACTION

Fit the heater properly in the socket.

CHECK

Is the heater burned out?

ACTION

If the result indicates that the heater has burned out, replace it.

● S-E is indicated.
(in T/C mode, auto T/C mode)

CHECK

Is the thermocouple connected to the preheater body?

ACTION

Connect the thermocouple to the preheater body.

CHECK

Does the thermocouple have an open circuit?

ACTION

If feasible, correct the open circuit; otherwise, replace the thermocouple.

● H-E is indicated.
(in T/C mode, auto T/C mode)

CHECK

Is the selector switch off?

ACTION

Turn on the selector switch.

CHECK

Is the heater burned out or out of place?

ACTION

See "● The heater is not powered."

CHECK

Is the setting for the heater power alert too low (set to too short a time)?

ACTION

Change the heater power alert to an appropriate setting.

CHECK

Is the location of measurement for the thermocouple inappropriate or is the thermocouple mounted improperly?

ACTION

Mount the thermocouple to an appropriate location of measurement.

● O-E is indicated
(in T/C mode, auto T/C mode)

CHECK

Is the setting for the temperature upper limit too low?

ACTION

Change the temperature upper limit to an appropriate setting.

● U-E is indicated.
(in T/C mode, auto T/C mode)

CHECK

Is the setting for the temperature lower limit too high?

ACTION

Change the temperature lower limit to an appropriate setting.

● The heater fails to exert control, the control mechanism is not normal, or the temperature indication remains unchanged.

CHECK

Is the thermocouple displaced from the location of measurement or is it mounted improperly?

ACTION

Mount the thermocouple in an appropriate location of measurement.

● Settings cannot be edited. The mode cannot be changed.

CHECK

Is the protection level C-2 or higher?

ACTION

By referring to "● Editing the Parameters", change the protect level to one that permits changing of the settings.

● The unit turns off suddenly while running.

CHECK

Is the Auto power shutoff set?


ACTION

Turn OFF the power switch and then back ON. By referring to "● Editing the Parameters", change the Auto shutoff time.


9. ERROR MESSAGES

All error indications occur only in T/C mode or T/C auto mode.


● Sensor error




● Heater error



● Temperature upper limit setting error



● Temperature lower limit setting error



⚠ CAUTION

All error indications will remain until the preheater is turned off and then back on.


S-E is indicated when the thermocouple is not properly connected to the preheater body or has an open circuit.

H-E is indicated when the selector switch is off or the heater lamp has burned out or is detached from the preheater body.H-E is also indicated when the heater power alert goes on.

O-E is indicated when the temperature rises above the predetermined upper limit for some reason after it has stabilized during preheating.

U-E is indicated when the temperature drops below the predetermined lower limit for some reason after it has stabilized during preheating.

11. PARTS LIST




● HAKKO FR-872

Item No.	Part No.	Part Name	Specifications
①	A5003	Heater	100-120V
	A5004	Heater	220-240V
②	B5039	Fuse / 250V-15A	100-120V
	B3674	Fuse / 250V-7A	220-240V
③	B3516	Thermo couple	
④	B3658	P.W.B. holder	
⑤	B3704	Switch	For power Supply
⑥	B3656	Switch	For zone selector

⑦

Item No.	Part No.	Part Name	Specifications
⑦	B5042	Power cord, 3-wire cord & American plug	120V USA
	B2422	Power cord, 3-wire cord & BS plug	India
	B2424	Power cord, 3-wire cord & European plug	230V CE
	B2436	Power cord, 3-wire cord & Chinese plug	China
	B3508	Power cord, 3-wire cord & American plug (B)	

①



● Optional parts

Item No.	Part No.	Part Name	Specifications
①	B3686	Connecting cable	For FM-206