

# フィルターの セット方法

- ① 前ホルダーに  
スプリングフィルターを  
取り付けます


先がへこんでい  
たら出してから  
取り付け  
下さい。



スプリングフィルター  
スプリングフィルターは前ホルダーの  
奥までピッタリと取り付けして下さい。


- スプリングフィルターのスプリングがのびて間があると、フィルターの寿命が短くなりますので、交換して下さい。

- ② フィルターパイプを  
取り付けます



前ホルダーとフィルターパイプの  
間にすきまができないようピッタリと  
取り付けして下さい。

- ③ セラミックペーパーフィル  
ター(L)を取り付けます




- スプリングフィルターと反対の方向から入れて下さい。
- パイプとセラミックペーパーフィルター(L)の間にすきまができないよう止まるところまでまっすぐ入れて下さい。

## 更換過濾裝置 日本白光牌

- ① 將彈簧過濾管安裝在前端蓋。


前端蓋      彈簧過濾管



將彈簧過濾管  
穩裝在前端蓋。

- 張拉彈簧過濾管，或者綫圈之間有罅縫，都會縮短其使用壽命與減弱其操作功能。


- ② 將前端蓋安裝在過濾管上。



- 將前端蓋安裝在過濾管上，不使空氣漏出。

- ③ 更換陶瓷過濾紙(大)。

前端蓋      陶瓷過濾紙(大)




- 將陶瓷過濾紙(大)放在彈簧過濾管對邊。
- 將陶瓷過濾紙(大)整齊地放進過濾管，防止漏氣。

## Replacing the Filters

- ① Attach the Spring Filter to the Front Holder


Front Holder      Spring Filter



Firmly attach the Spring Filter to the Front Holder.

- Stretching the Spring Filter or allowing gaps between the coils will reduce the service life and effectiveness of the Filter. If the Filter displays either of these conditions, replace it with a new one.

- ② Attach the Front Holder to the Filter Pipe.



- Attach the Front Holder to the Filter Pipe. Check to make sure that it doesn't leak.

- ③ Replace the Ceramic Paper Filter (L)

Front Holder      Ceramic Paper Filter (L)



- Place the Ceramic Paper Filter(L) on the opposite side from the Spring Filter.
- Place the Ceramic Paper Filter(L) snugly against the Filter Pipe to prevent leakage.