


△注意
表示をよく見て、バーコードリーダーとテスターのDサブレセプタクルを間違えずに接続してください。

△注意
請仔細察看標示，連接時注意勿弄錯條形碼讀取器和溫度計的D副插座。

△CAUTION
Check the labels carefully and be sure to connect the barcode reader and tester to the proper D-sub receptacles.



白光株式会社

<http://www.hakko.com>

〒556-0024 大阪市浪速区塩草2丁目4番5号
TEL: (06) 6561-1574 (代) FAX: (06) 6568-0821

© 2019 HAKKO Corporation. All Rights Reserved.

その他の会社名と製品名は各社の商標または登録商標です。



HAKKO CORPORATION

HEAD OFFICE

4-5, Shiokusa 2-chome, Naniwa-ku, Osaka 556-0024 JAPAN

TEL: +81-6-6561-3225 FAX: +81-6-6561-8466

<http://www.hakko.com> E-mail: sales@hakko.com

OVERSEAS AFFILIATES

U.S.A.: AMERICAN HAKKO PRODUCTS, INC.

TEL: (661) 294-0090 FAX: (661) 294-0096

Toll Free (800) 88-HAKKO

<http://www.hakkousa.com> E-mail: support@hakkousa.com

HONG KONG: HAKKO DEVELOPMENT CO., LTD.

TEL: 2811-5588 FAX: 2590-0217

<http://www.hakko.com.cn> E-mail: info@hakko.com.hk

SINGAPORE: HAKKO PRODUCTS PTE., LTD.

TEL: 6748-2277 FAX: 6744-0033

<http://www.hakko.com.sg> E-mail: sales@hakko.com.sg

Please access to the following address for the other Sales affiliates.

<http://www.hakko.com>

© 2019 HAKKO Corporation. All Rights Reserved.

Company and product names are trademarks or registered trademarks of their respective companies.


HAKKO

ADAPTER MODULE

C5055

セット内容と各部名称


アダプターモジュール	1	RS232Cケーブル	1
DINケーブル	1	取扱説明書	1



組立て


●温度計(ハッコーFG-101B)との接続

1. ハッコーFN-1010とハッコーFG-101Bの電源をOFFにします。
2. 右図のようにRS232Cケーブル、DINケーブルを接続します。
3. ハッコーFN-1010とハッコーFG-101Bの電源をONにします。



●バーコードリーダーとの接続

1. ハッコーFN-1010の電源をOFFにします。
2. 右図のようにバーコードリーダーを接続します。
3. ハッコーFN-1010の電源をONにします。




【注記】

バーコードリーダーは弊社C5009のご使用を推奨いたします。

ADAPTER MODULE C5055

包裝內容及各部名稱


適配模塊	1	RS232C線	1
DIN線	1	使用說明書	1



組裝


●與溫度計 (HAKKO FG-101B) 的連接

1. 關閉 (OFF) HAKKO FN-1010和HAKKO FG-101B的電源。
2. 如右圖所示連接RS232C線、DIN線。
3. 打開 (ON) HAKKO FN-1010和HAKKO FG-101B的電源。



●與條形碼讀取器的連接

1. 關閉 (OFF) HAKKO FN-1010的電源。
2. 如右圖所示連接條形碼讀取器。
3. 打開 (ON) HAKKO FN-1010的電源。




註記：
推薦的條形碼讀出器是C5009。

ADAPTER MODULE C5055

PACKING LIST AND PART NAMES


Adapter module	1	RS232C cable	1
DIN cable	1	Instruction manual	1



ASSEMBLY


●Connecting the thermometer (HAKKO FG-101B)

1. Turn off the power of the HAKKO FN-1010 and HAKKO FG-101B.
2. Connect the RS232C cable and DIN cable as shown at right.
3. Turn on the power of the HAKKO FN-1010 and HAKKO FG-101B.



●Connecting the barcode reader

1. Turn off the power of the HAKKO FN-1010.
2. Connect the barcode reader as shown at right.
3. Turn on the power of the HAKKO FN-1010.



NOTE:
The recommended bar code reader is C5009.