

HAKKO

SOLDER FEED PULLEY UNIT / 0.3 mm BX1076

本製品はφ0.3 mm はんだ用はんだ送りプーリーユニットです。

This product is a solder feed pulley unit for φ0.3 mm solder.

本产品是用于φ0.3 mm 焊锡的送锡滑轮装置。

はんだのセット方法 / How to set solder / 锡线的设置方法

- ① はんだ送りプーリーユニットの供給ノズルを外します。

Remove the supply nozzle from the solder feed pulley unit.

拆下送锡滑轮组件的送锡嘴。

- ② はんだ送りプーリーユニットをフィーダーユニットに取り付けます。


Attach the solder feed pulley unit to the feeder unit.

将送锡滑轮装置安装于送锡装置上。

- ③ はんだを挿入し、下図のように送り出します。

Insert and feed the solder as shown in the following figure.


插入锡线，如下图所示将锡线送出。



- ④ 供給ノズルにはんだを通し、はんだ送りプーリーユニットに差し込みます。

Pass the solder through the supply nozzle and insert it into the solder feed pulley unit.

将焊锡穿过送锡嘴，插入送锡滑轮装置。



白光株式会社

<https://www.hakko.com>

〒556-0024 大阪市浪速区塩草2丁目4番5号

TEL: (06) 6561-1574 (代) FAX: (06) 6568-0821

HAKKO CORPORATION

HEAD OFFICE

4-5, Shiokusa 2-chome, Naniwa-ku, Osaka 556-0024 JAPAN

TEL: +81-6-6561-3225 FAX: +81-6-6561-8466

<https://www.hakko.com> E-mail: sales@hakko.com

OVERSEAS AFFILIATES

U.S.A.: AMERICAN HAKKO PRODUCTS, INC.

TEL: (661) 294-0090 FAX: (661) 294-0096

Toll Free (800) 88-HAKKO

<https://www.HakkoUSA.com> E-mail: Support@HakkoUSA.com

CHINA: HAKKO DEVELOPMENT CO., LTD.

TEL: (020) 8135-0112, 8135-0113, 8135-1086 FAX: (020) 8135-0181

<https://www.hakko.com.cn> E-mail: sales@hakko.gz.cn

SINGAPORE: HAKKO PRODUCTS PTE., LTD.

TEL: 6748-2277 FAX: 6744-0033

<https://www.hakko.com.sg> E-mail: sales@hakko.com.sg

Please access the code for overseas distributors.

https://www.hakko.com/doc_network



© 2026 HAKKO Corporation. All Rights Reserved.

2026.4
80.1112-001