



SMDリワークステーション
扁平集成电路拔放臺
SMD Rework Station

温度分布表 温度分布圖表 TEMPERATURE DISTRIBUTION CHART

△ 注意

- グラフは参考用値であり、規格値ではありません。
- サーマルプロテクターが働く場合は温度設定を下げるか、風量を上げるように調節してください。
- FR-801をご使用の際にはノズル別温度分布表を参考にしてください。
- FR-801はハッコー850及びハッコー850Bとは異なります。よって、温度分布表も異なりますので、ご注意ください。

- 測定条件：ノズル先端より1mmの位置で記録計により測定。
- () 内は温度特性同等品です。

△ 注意

- 温度分布圖表使用于参考，并不是規格值。
- 熱度保護器起動時，請將溫度降低或將風量提高以做調節。
- 使用FR-801時，請參考不同噴嘴的溫度分布圖表。
- FR-801与HAKKO 850及850B不同，溫度分布圖表也不同，請注意。

- 測量條件:距離噴氣嘴3毫米處測量。
- 噴嘴番号下面的()内，是溫度特性的同等品。

△ CAUTION

- These charts do not define the temperature characteristics, and are for reference only. If the thermal protector trips, reduce the temperature setting or increase the air flow.
- The temperature distribution charts for HAKKO 850 or 850B should not be used for FR-801. FR-801 uses a different pump and control system. When you use the FR-801, make sure to refer to the temperature distribution charts shown to the right.

- Test condition: Measured at a point 1mm (0.04 in.) from the nozzle by recorder.
- Nozzles of which part names are parenthesized have equivalent temperature characteristics.



白光株式会社
http://www.hakko.com
〒556-0024 大阪市浪速区塩草2丁目4番5号
TEL: (06) 6561-1574 (代) FAX: (06) 6568-0821



HEAD OFFICE
TEL: +81-6-6561-3225 FAX: +81-6-6561-8466
http://www.hakko.com E-mail: sales@hakko.com
OVERSEAS AFFILIATES
U.S.A.: AMERICAN HAKKO PRODUCTS, INC.
TEL: (001) 294-0090 FAX: (001) 294-0090
Toll Free (800)88-HAKKO
http://www.hakkousa.com
HONG KONG: HAKKO DEVELOPMENT CO., LTD.
TEL: 2811-5588 FAX: 2590-0217
http://www.hakko.com.hk
E-mail: info@hakko.com.hk
SINGAPORE: HAKKO PRODUCTS PTE., LTD.
TEL: 6748-2277 FAX: 6744-0033
http://www.hakko.com.sg
E-mail: sales@hakko.com.sg

Please access to the following address for the other Sales affiliates.


http://www.hakko.com

Copyright © 2006 HAKKO Corporation. All Rights Reserved.

2007.7
MA01492JZ07030


A1124B (A1142B)

温度／溫度／Temp.




A1125B (A1139B)

温度／溫度／Temp.




A1126B (A1180B)

温度／溫度／Temp.




A1127B (A1135B, A1136B, A1181B)

温度／溫度／Temp.



A1128B


温度／溫度／Temp.



A1129B


(A1138B, A1265B)

温度／溫度／Temp.



A1130


温度／溫度／Temp.



A1131


(A1132, A1183, A1190, A1185B, A1187B, A1258B)

温度／溫度／Temp.



A1257B (A1184B, A1186B, A1188B, A1214B, A1259B, A1260B, A1133, A1134, A1191, A1325)


温度／溫度／Temp.



A1261B

(A1137B, A1182B, A1192)


温度／溫度／Temp.



A1262B

(A1140B, A1141B)

温度／溫度／Temp.



A1264B

(A1189B, A1203B, A1215B, A1263B)

温度／溫度／Temp.

