# 日本白光牌 雷池式焊鐵

### 關於產品

本産品為使用電氣發熱元件之焊鐵。焊鐵頭與其所連 接金屬部分會達到攝氏300度以上之高温。使用之前 請務必閱讀本紙之説明及請正確使用。本紙請與産品 -起慎重保管,讓要使用的人一定能够讀到。

## ⚠ 注意


鑒於濫用可能導致灼傷或火患,請嚴格遵守以下事項

- ●使用中之焊鐵頭温度極高。切勿碰觸身體或周圍之
- ●切勿使用於焊接以外之用途。
- ●切勿加以強烈衝擊。
- ●焊接時會産生煙氣, 請注意通風。
- ●切勿使用純正部件以外之物,或加以改造、分解。
- ●小孩之使用請在保護者的指導之下進行。
- ●切勿將新電池與使用過之電池、不同種類之乾電池 混合使用。
- ●請確認乾電池之正負極, 正確裝入。
- ■關於電池之使用,請閱讀電池之使用説明書。
- ●使用後請務必套上蓋子。
- ●存放時請取出乾電池。

乾電池請另行自備。

乾電池請務必使用鹼性5號乾電池3個。

乾電池請依照圖示方向裝入。



# Hakko 746 Battery powered soldering iron

## About this product

This soldering iron uses an electric heating element. The tip temperature and the metal parts near the tip can reach over of 300° C. Before using your new soldering iron, be sure to read these instructions carefully in order to use the soldering iron correctly. Keep these instructions with the soldering iron so that anyone who uses it can refer to the instructions.

# CAUTION

Mishandling may lead to burns or fire, be sure to comply with the following precaution:

- The tip is extremely hot during use. Avoid contact with hands, skin, and other objects.
- Do not use this unit for anything other than soldering.
- Do not strike the unit or otherwise subject the unit to strong physical shock.
- Smoke is emitted when soldering is conducted. Be sure to provide sufficient ventilation.
- Be sure to use only genuine replacement parts. Do not modify or disassemble the unit.
- Do not allow children to use the unit without adult supervision.
- When replacing batteries, replace all of the batteries with the correct type. Do not mix new batteries with old batteries or batteries of a different type.
- Be sure to insert the batteries properly (+/-).
- See the instructions provided with the batteries regarding how to handle the batteries properly.
- Be sure to attach the cap to the unit after use.
- Be sure to remove the batteries before storing the unit.

### 使用方法

- 1. 取下蓋子,將滑動開關移到ON。在OFF位置按下按 鈕也不會通電。
- 2. 按住按鈕時會亮燈, 焊鐵頭開始加熱, 30秒鐘即可 達到焊接之溫度。
- 3. 焊接完畢之後,請將手指従按鈕移開。有效重複此 按鈕操作,即可控制溫度,並能延長電池之壽命。
- 4. 作業結束後, 請務必在焊鐵頭塗抹預備焊錫, 將開 關移到OFF, 套上蓋子, 並取出電池。

### 扳手使用方法

請參考左圖,將扳手插到箭頭地方抬起來,取出焊鐵頭。

規格	
產品	Hakko746
功率消耗	6 瓦特
外觀尺寸	175(寬)×35(高)×20(深)mm (不含蓋子)
重 量	66g (不含乾電池)
使用雷池	鹼性5號乾電池 3個

### **亩協並**件

ZIXIIII				
編號	名	稱		
T 3 - B	焊鐵頭	B型		
T3-BC	焊鐵頭	BC型		
T 3 — D	焊鐵頭	D型		

標準附屬品: 焊鐵頭B型, 扳手, 蓋子



### **OVERSEAS AFFILIATES**

U.S.A. AMERICAN HAKKO PRODUCTS, INC. TEL: (661) 294-0090 FAX: (661) 294-0096 Toll Free (800)88-HAKKO

http://www.hakkousa.com http://www.hakkousa.com HONG KONG HAKKO DEVELOPMENT CO., LTD. TEL: 2811-5588 FAX: 2590-0217 http://www.hakko.com.hk/ CHINA HAKKO DEVELOPMENT CO., LTD. TEL: (20)9435-0412, 9436-0413

TEL: (020)8135-0112, 8135-0113 FAX: (020)8135-0181

HAKKO DEVELOPMENT CO., LTD. TEL: (02)8512-4588 FAX: (02)8512-4258

### **HEAD OFFICE**

4-5, SHIOKUSA 2-CHOME, NANIWA-KU, OSAKA, 556-0024 JAPAN TEL:+81-6-6561-3225 FAX:+81-6-6561-8466 http://www.hakko.com

SINGAPORE


SINGAPORE
HAKKO PRODUCTS PTE., LTD.
TEL: 748-2277 FAX: 744-0033
MALAYSIA
HAKKO PRODUCTS SDN BHD
MALAYSIA HEAD OFFICE
TEL: (03)519-5221 FAX: (03)519-5221
PENANG BRANCH
TEL: (04)507-0988 FAX: (04)507-0999
JOHORE BAHRU BRANCH TEL: (07)236-7766 FAX: (07)237-4655

PHILIPPINES
HAKKO PHILS TRADING CO., INC.
TEL: (02)817-0712, 815-4993 FAX: (02)810-7649
INDONESIA
P.T. HAKKO PRODUCTSTAMA INDONESIA TEL: (778)457-459 FAX: (778)452-772 P.T. HAKKO PRODUCTSTAMA INDONESIA

TEL: (21)532-4083 FAX: (21)532-4082

2000.6 MA00948XZ000619

Batteries are not included with this unit. Use only AA size alkaline batteries. Insert three batteries as shown in the figure.



## **Operation instructions**

- 1. Remove the cap and move the sliding switch to ON. The button will not function if the switch is set to OFF.
- 2. Press the button. The indicator lamp will illuminate and the tip will begin to heat up. In 30 seconds the tip will be sufficiently hot for soldering.
- 3. Release your finger from the button after completing each soldering joint. By efficiently pressing and releasing the button, you can control the tip temperature and extend the life of the batteries.
- 4. After use, tin the tip (i.e., apply a thin layer of solder to the tip) and turn the switch OFF. Close the cap and remove the batteries.

### How to use wrench

Insert the wrench to the point shown by an arrow, then push it up to remove the tip.

### Specification

Name	Hakko746	
Power consumption	6W	
Outer dimensions	175(L)×35(H)×20(W)mm	(w/o cap)
Weight	66g (w/o batteries)	
Batteries	Alkaline batteries AA	

### Replacement parts

Part No.	Part name			
T 3 - B	Tip B type			
T3-BC	Tip BC type			
T3-D	Tip D type			

accessory: Tip type B, wrench, cap.